



## ALIGNMENT PROCEDURE

Steps in Alignment	Test Oscillator					
	Connection to Receiver	Dummy Antenna	Frequency Setting	Receiver Dial Setting	Circuit to Adjust	Symbol on Schematic
1.	Control Grid 12SK7 Pin No. 4	.05 Mfd.	456 Kc.	No Signal 540-700 Kc.	2nd LF. Transformer	Adjustable Iron Core
2.	Control Grid 12SA7 Pin No. 8	.05 Mfd.	456 Kc.	No Signal 540-700 Kc.	1st I.F. Transformer	C6A C6B
3.	Antenna Clip Back of Chassis	50 Mmfd.	1500 Kc.	1500 Kc.	Oscillator Trimmer	C4
4.	Antenna Clip Back of Chassis	50 Mmfd.	1500 Kc.	1500 Kc.	Antenna Trimmer	C3